

tvcabo

**MANUAL DE
CONFIGURAÇÃO**

ONT HG8247H5

ONT HG8247H5




APRESENTAÇÃO/DESCRIÇÃO DO EQUIPAMENTO

A ONU HG8247h5 é um modelo que opera em frequências de 2.4 GHz

IMAGENS



APRESENTAÇÃO/DESCRIÇÃO
DO EQUIPAMENTO



1. Entrada CATV
2. Entrada Óptica (fibra óptica)
3. Botão power (Ligar / Desligar)
4. Entrada / fonte de alimentação - 12v
5. Entrada USB
6. Porta RJ11 (telefone)
7. Portas RJ45 (Entradas LANS)

PROCEDIMENTO DE
CONFIGURAÇÃO PARA REDE WI-FI


1. Coloque na barra de ferramenta o seguinte IP:
192.168.100.1 em seguida clique **ENTER**.

Insira as seguintes credenciais:

User: **root**

Password: **admin**

Log In:



PROCEDIMENTO DE
CONFIGURAÇÃO PARA REDE WI-FI

2. Carregar em WLAN

On this page, you can set basic WLAN parameters. (When the WLAN function is disabled, this page is blank).

Caution

1. Wireless network services may be interrupted temporarily after you modify wireless network parameters.
2. It is recommended that you use the WPA2 or WPA/WPA2 authentication mode for security purposes.

☒ **Enable WLAN** New Delete

SSID Index	SSID Name	SSID Status	Number of Associated Devices	Broadcast SSID	Security Configuration
1	TVCABO-WIFI	Enabled	32	Enabled	Configured

SSID Configuration Details

SSID Name: * (1-32 characters)

Enable SSID: ☒

Number of Associated Devices: * (1-32)

Broadcast SSID: ☒

Enable WMM: ☒

Authentication Mode:

Encryption Mode:

WPA PreSharedKey: ☒ Hide * (8-63 characters or 64 hexadecimal characters)

WPA Group Key Regeneration Interval: *(500-86400s)

Enable WPS: ☐

WPS Mode:

PBC:

Copyright © Technologies Co., Ltd. 2022-2030. All rights reserved.

SSDI NAME» **Nome da rede**WPA Presharedkey» **Senha da rede**

PROCEDIMENTO DE CONFIGURAÇÃO PARA REDE WI-FI

SSID NAME» **Nome da rede**

WPA Presharedkey» **Senha da rede**

HG8247H5 Logout

Status WAN LAN IPv6 **WLAN** Security Route Forward Rules Network Application Voice System Tools

WLAN Basic Configuration
WLAN Advanced Configuration
Automatic WiFi Shutdown
WiFi Coverage Management

WLAN > WLAN Basic Configuration

On this page, you can set basic WLAN parameters(When the WLAN function is disabled, this page is blank).
⚠ Caution
1. Wireless network services may be interrupted temporarily after you modify wireless network parameters.
2. It is recommended that you use the WPA2 or WPA/WPA2 authentication mode for security purposes.

☒ Enable WLAN New Delete

SSID Index	SSID Name	SSID Status	Number of Associated Devices	Broadcast SSID	Security Configuration
1	TVCABO-WIFI	Enabled	32	Enabled	Configured

SSID Name: TVCABO-WIFI * (1-32 characters)

Number of Associated Devices: 32 * (1-32)

Broadcast SSID: ☒

Enable WMM: ☒

Authentication Mode: WPA/WPA2 PreSharedKey

WPA PreSharedKey: ***** Hide * (8-63 characters or 64 hexadecimal characters)

Interval: 3600 (1-3600 seconds)

Enable WPS: ☐

WPS Mode: PBC

PBC: ☐

Apply **Cancel**

Copyright © Technologies Co., Ltd. 2022-2030. All rights reserved.

APPLY » **Guardar as configurações feitas.**

tv cabo

tv cabo@tv cabo.co.ao
www.tv cabo.ao

